

Architectural Door Accessories

ASSA ABLOY

Pemko Door Bottoms

The global leader in
door opening solutions


Applies to the following door bottom:

2170_V

Installation Instructions:

1. Measure, mark and trim door bottom shoe to full width of door.
2. Slide door bottom shoe in place and close door. Position so that it makes light even contact with the threshold. Mark door in center of slotted holes.
3. Drill pilot holes in door at marks.
4. Secure door bottom shoe to door with supplied screws. Adjust to ensure light even contact with threshold.

Tools Required:



www.pemko.com

MEMPHIS, TN USA	VENTURA, CA USA	VANCOUVER, BC CA	TORONTO, ON CA
P: 800 824-3018	P: 800 283-9988	P: 877 535-7888	P: 877 535-7888
F: 800 243-3656	F: 800 283-4050	F: 877 535-7444	F: 877 535-7444

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved.
Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.

DB24_WEBINS
Rev 2 - 03.07.17
Page 1 of 1