Architectural Door Accessories

ASSA ABLOY

Pemko Residential Threshold

The global leader in door opening solutions

Applies to the following products:

324, 3261, 326, 327

Installation Instructions:

- 1. Measure, mark, and trim sill nosing to desired length. If necessary, trim (notch) around door jambs.
- 2. Secure using construction grade adhesive (or caulking) to bond metal nosing to concrete sill to be covered (adhesive not included).
- 3. If intended for use with pre-installed threshold, loosen threshold screws, slip top leg of nosing under outside leg of threshold and adhere as described in step 2.

Testing/Ratings:

Tools Required:

