

Architectural Door Accessories

ASSA ABLOY

Pemko Brush Gasketing

The global leader in
door opening solutions

Applies to the following products:

90100_NB, 90137_NB

Installation Instructions:

CUTTING BRUSH:

1. Remove brush prior to cutting.
2. Trim off excess brush using Lineman Side Cutting Pliers and crimp the brush filament ends.
3. Re-insert the brush until it is flush with one end of the retainer and crimp to hold in place.

DOOR BOTTOMS:


1. Measure, mark and trim door bottom sweep to full width of door.
Important note: when trimming, pull out section of brush seal to be trimmed and use Lineman Side Cutting Pliers to pinch end of seal. This will retain the brush. Trim will retain the brush. Trim aluminum (or oak) retainer with a hacksaw.
2. Close door and position door bottom sweep along outside bottom edge of door so that it makes firm contact with threshold. Mark door in center of slotted holes.
3. Drill pilot holes in door at marks.
4. Secure door bottom sweep to door with supplied screws. Adjust to ensure firm contact with threshold.

Testing/Ratings:

Gasketing material for fire doors intended for application to listed steel frames and/or classified steel covered composite type, and hollow metal type fire doors rated up to 3 hours; wood and plastic covered composite type fire doors rated up to 1-1/2 hours; and wood core type fire doors rated up to 20 minutes.
(Thresholds may or may not contain gasketing material).



Tools Required:



www.pemko.com

MEMPHIS, TN USA VENTURA, CA USA VANCOUVER, BC CA TORONTO, ON CA
P: 800 824-3018 P: 800 283-9988 P: 877 535-7888 P: 877 535-7888
F: 800 243-3656 F: 800 283-4050 F: 877 535-7444 F: 877 535-7444

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved.
Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.

BR9_WEBINS
Rev 3 - 01.25.17
Page 1 of 1